

FRONT

- Advance Mode can be used for professional and high secure management. Normal Mode is enough for general use, because managing Advance Mode is more complicated than Normal Mode.

1. Change Mode (Normal Mode → Advance Mode)

Method ① → # → 4,1 → Master PIN Code → ①

- When already Advance Mode, this process doesn't work
- User Pin Code is removed after changing mode

2. Change Master PIN Code (Old → New)

Method ① → # → 0,9 → (Old) Master PIN Code → # → (New) Master PIN Code → ①

- When Normal Mode, this process doesn't work

3. One Time User PIN Code

Method ① → # → 0,7 → Master PIN Code → # → One Time User PIN Code → ①

- When Normal Mode, this process doesn't work

4. Change Mode (Advance Mode → Normal Mode)

Method ① → # → 4,3 → Master PIN Code → ①

- When already Normal Mode, this process doesn't work
- Current Master PIN Code is changed to User PIN Code

To register User PIN Code / Card Key / Fingerprint

1. When Normal Mode

Method ① → User PIN Code or Card Key or Fingerprint → ①

2. When Advance Mode

Method Master PIN Code → ① → User PIN Code or Card Key or Fingerprint → ①

! Important

- Master PIN Code ≠ User PIN Code ≠ One Time PIN Code.
- When Advance Mode, Fake PIN Code cannot be used.
- It is impossible to change mode by using Card Key, User PIN Code and One Time PIN Code.
- When mode change from Advance Mode to Normal Mode.
 - Most registration information(Card Key, User PIN Code, One Time PIN Code, Fingerprint) is removed.
 - Current Master PIN Code is changed to User PIN Code.
 - Remote controller information is not removed.
- When mode change from Normal Mode to Advance Mode.
 - Most registration information(Card Key, User PIN Code, Fingerprint) is removed.
 - Remote controller information is not removed.
- One Time PIN Code doesn't support setting of Outside Forced Lock and Releasing Alarm.

BACK

簡易說明書

1. 變更模式 (一般模式 → 進階模式)

方法 ① → # → 4,1 → 按[管理者密碼] → ①

- 如在[進階模式]的狀態下,本操作不能完成
- 如完成本設定變更,已登記的[使用者密碼]將自動消失

2. 變更[管理者密碼] ([管理者密碼]重新登記)

方法 ① → # → 0,9 → 按原本的管理者密碼 → # → 輸入新的管理者密碼 → ①

- 如在[一般模式]的狀態下,不能使用此設定

3. 登記[一次性密碼]

方法 ① → # → 0,7 → 按[管理者密碼] → # → 輸入[一次性密碼] → ①

- 如在[一般模式]狀態下,不能使用此設定

4. 變更模式 (進階模式 → 一般模式)

方法 ① → # → 4,3 → 按[管理者密碼] → ①

- 如在[一般模式]狀態下,不能使用此設定
- 已登記的[管理者密碼]自動變成[使用者密碼]

登記 [使用者密碼] / [卡片/指紋]

1. 在[一般模式]的狀態下

方法 ① → 輸入[使用者密碼/卡片/指紋] → ①

2. 在[進階模式]的狀態下

方法 管理者密碼 → ① → 輸入[使用者密碼/卡片/指紋] → ①

! 注意

- 【管理者密碼】· 【使用者密碼】和【一次性密碼】必須要有不同的數位組合
- 在【進階模式】的狀態下· 不能用虛位元密碼功能
- 無法使用【使用者密碼】或【卡片】或【一次性密碼】來操作變更模式的流程
- 如從【進階模式】變更到【一般模式】狀態下：
 - 已登記的所有【使用者密碼/卡片/指紋/一次性密碼】將自動消失
 - 已登記的【管理者密碼】自動變成【使用者密碼】
 - 已登記的遙控器可以繼續使用
- 如從【一般模式】變更到【進階模式】狀態下：
 - 已登記的所有【使用者密碼/卡片/指紋/一次性密碼】將自動消失
 - 已登記的遙控器可以繼續使用
- 使用【一次性密碼】時· 不能設置【從外部強制鎖定】功能及相關警報