

# FRONT

- Advance Mode can be used for professional and high secure management. Normal Mode is enough for general use, because managing Advance Mode is more complicated than Normal Mode.

## 1. Change Mode (Normal Mode → Advance Mode)

Method ① → # → 4,1 → Master PIN Code → ①

- When already Advance Mode, this process doesn't work
- User Pin Code is removed after changing mode

## 2. Change Master PIN Code (Old → New)

Method ① → # → 0,9 → (Old) Master PIN Code → # → (New) Master PIN Code → ①

- When Normal Mode, this process doesn't work

## 3. One Time User PIN Code

Method ① → # → 0,7 → Master PIN Code → # → One Time User PIN Code → ①

- When Normal Mode, this process doesn't work

## 4. Change Mode (Advance Mode → Normal Mode)

Method ① → # → 4,3 → Master PIN Code → ①

- When already Normal Mode, this process doesn't work
- Current Master PIN Code is changed to User PIN Code

## To register User PIN Code / Card Key / Fingerprint

### 1. When Normal Mode

Method ① → User PIN Code or Card Key or Fingerprint → ①

### 2. When Advance Mode

Method Master PIN Code → ① → User PIN Code or Card Key or Fingerprint → ①

## ! Important

- Master PIN Code ≠ User PIN Code ≠ One Time PIN Code.
- When Advance Mode, Fake PIN Code cannot be used.
- It is impossible to change mode by using Card Key, User PIN Code and One Time PIN Code.
- When mode change from Advance Mode to Normal Mode.
  - Most registration information(Card Key, User PIN Code, One Time PIN Code, Fingerprint) is removed.
  - Current Master PIN Code is changed to User PIN Code.
  - Remote controller information is not removed.
- When mode change from Normal Mode to Advance Mode.
  - Most registration information(Card Key, User PIN Code, Fingerprint) is removed.
  - Remote controller information is not removed.
- One Time PIN Code doesn't support setting of Outside Forced Lock and Releasing Alarm.

# BACK

## 簡易說明書

### 1. 變更模式 (一般模式 → 進階模式)

方法 ① → # → 4,1 → 按[管理者密碼] → ①

- 如在[進階模式]的狀態下,本操作不能完成
- 如完成本設定變更,已登記的[使用者密碼]將自動消失

### 2. 變更[管理者密碼] ([管理者密碼]重新登記)

方法 ① → # → 0,9 → 按原本的管理者密碼 → # → 輸入新的管理者密碼 → ①

- 如在[一般模式]的狀態下,不能使用此設定

### 3. 登記[一次性密碼]

方法 ① → # → 0,7 → 按[管理者密碼] → # → 輸入[一次性密碼] → ①

- 如在[一般模式]狀態下,不能使用此設定

### 4. 變更模式 (進階模式 → 一般模式)

方法 ① → # → 4,3 → 按[管理者密碼] → ①

- 如在[一般模式]狀態下,不能使用此設定
- 已登記的[管理者密碼]自動變成[使用者密碼]

## 登記 [使用者密碼] / [卡片/指紋]

### 1. 在[一般模式]的狀態下

方法 ① → 輸入[使用者密碼/卡片/指紋] → ①

### 2. 在[進階模式]的狀態下

方法 管理者密碼 → ① → 輸入[使用者密碼/卡片/指紋] → ①

## ! 注意

- 【管理者密碼】· 【使用者密碼】和【一次性密碼】必須要有不同的數位組合
- 在【進階模式】的狀態下· 不能用虛位元密碼功能
- 無法使用【使用者密碼】或【卡片】或【一次性密碼】來操作變更模式的流程
- 如從【進階模式】變更到【一般模式】狀態下：
  - 已登記的所有【使用者密碼/卡片/指紋/一次性密碼】將自動消失
  - 已登記的【管理者密碼】自動變成【使用者密碼】
  - 已登記的遙控器可以繼續使用
- 如從【一般模式】變更到【進階模式】狀態下：
  - 已登記的所有【使用者密碼/卡片/指紋/一次性密碼】將自動消失
  - 已登記的遙控器可以繼續使用
- 使用【一次性密碼】時· 不能設置【從外部強制鎖定】功能及相關警報